

A350MANUEL SECURITE SAUVETAGE

ABNORMAL/EMERGENCY PROCEDURES SMOKE AND FIRE PROCEDURES

CABIN CREW REST COMPARTMENT SMOKE PROCEDURE

Applicable to: ALL

When smoke is detected in the CCRC.

In the CCRC

- Visual alerts:
 - The AIP indicates the affected area in a red flashing alert info box
 - The lighting is automatically set to 100 % intensity.
- Aural alerts:
 - After a single triple low chime sounds (smoke alert), a sequence of 4 low chimes (wake up chime) sounds for 30 s then, a triple low chime (smoke alert) sounds every 30 s (or CAM assigned value).

In the cabin:

- Visual alerts:
 - On the Flight Attendant Panel (FAP):
 - the SMOKE DETECTION page automatically appears and displays the location of the affected area, the SMOKE RESET key comes on steady red
 - The SMOKE RESET hard key comes on red steady.
 - All AIPs indicate the affected area in a red flashing alert info box
 - The related ACP flashes amber
 - The related CCRC smoke indicator flashes amber
 - The SMOKE RESET key on the related AAP comes on steady red.
- Aural alert:

- a triple low chime sounds every 30 seconds in the cabin (or CAM assignment value).



ABNORMAL/EMERGENCY PROCEDURES SMOKE AND FIRE PROCEDURES

A350MANUEL SECURITE SAUVETAGE

CABIN CREW REST COMPARTMENT SMOKE PROCEDURE (Cont'd)

amber smoke indicator next to the CCRC door, the Smoke reset on the FAP and APs, and the indications on the FAP SMOKE DETECTION page remain on as as smoke is detected.
Do not open the door before checking for heat. Move the back of the hand along the door to evaluate the presence/severity of the fire.
r is not hot: OOR
FIREFIGHTING PROCEDUREAPPLY
oke or fire is not visible: N SMOKE/FIRE IN HIDDEN AREA OR UNKNOWN SOURCE PROCEDURE APPLY
r is hot:
the door panel is hot, the fire is at a critical stage. Have extra fire fighting quipment available and ready to use.
DON ITERSELF PROTECT and crouch down, using the door panel as protection against smoke and heat. DOOROPEN SLIGHTLY
must be opened just enough to pass the nozzle of the extinguisher XTINGUISHERDISCHARGE DOOR
last three steps of the procedure, as necessary.
safe: DOOROPEN WITH CAUTION ICE OF SMOKE/FIRELOCATE h all bunks, closets, and stowage compartments.

FWI A350 FLEET 14-20 P 24/32 MSS ← N → 23 JAN 17

Continued on the following page



A350MANUEL SECURITE SAUVETAGE

ABNORMAL/EMERGENCY PROCEDURES SMOKE AND FIRE PROCEDURES

CABIN CREW REST COMPARTMENT SMOKE PROCEDURE (Cont'd)

If smoke or fire is visible:
 BASIC FIREFIGHTING PROCEDURE........APPLY

 If smoke or fire is not visible:
 CABIN SMOKE/FIRE IN HIDDEN AREA OR UNKNOWN SOURCE PROCEDURE.......APPLY

 When situation is cleared:
 CCRC......MONITOR FOR THE REMAINDER OF THE FLIGHT To ensure that the CCRC remains clear of smoke.