


Location of the OPEN DOOR Pushbutton

1. Press the OPEN DOOR pb to unlock the door.
2. Within 5 s, push the door handle and open the door. If not done within 5 s, the door will automatically relock and it will be necessary to repeat the steps 1 and 2.

HOW TO CLOSE THE DOORFrom Inside the FCRC

1. Grasp the door handle and carefully pull the door against the door frame.
2. Hold the door in this position until the door lock engages.

From the Cabin

1. Use the door handle to carefully push the door against the door frame.
2. Hold the door in this position until the door lock engages.