

ABNORMAL/EMERGENCY PROCEDURES SMOKE AND FIRE PROCEDURES

A350 MANUEL SECURITE SAUVETAGE

FLIGHT CREW REST COMPARTMENT SMOKE/FIRE PROCEDURE

Applicable to: ALL

When smoke is detected in the FCRC.

In the FCRC

- Visual alerts:
 - All AIPs indicate the affected area in a red flashing alert info box
 - The lighting is automatically set to 100 % intensity.
- Aural alerts:
 - After a single triple low chime sounds (smoke alert), a sequence of 4 low chimes (wake up chime) sounds for 30 s then, a triple low chime (smoke alert) sounds every 30 s (or CAM assigned value).

In the cabin:

- Visual alerts:
 - On the Flight Attendant Panel (FAP):
 - the SMOKE DETECTION page automatically appears and displays the location of the affected area, the SMOKE RESET key comes on steady red
 - The SMOKE RESET hard key comes on red steady.
 - All AIPs indicate the affected area in a red flashing alert info box
 - The related ACP flashes amber
 - The related FCRC smoke indicator flashes amber
 - The SMOKE RESET key on the related AAP comes on steady red.
- Aural alert:
 - a triple low chime sounds every 30 seconds in the cabin (or CAM assignment value).



A350MANUEL SECURITE SAUVETAGE

ABNORMAL/EMERGENCY PROCEDURES SMOKE AND FIRE PROCEDURES

FLIGHT CREW REST COMPARTMENT SMOKE/FIRE PROCEDURE (Cont'd)

If smoke or fire is not visible:

CABIN SMOKE/FIRE IN HIDDEN AREA OR UNKNOWN SOURCE PROCEDURE......

......APPLY

If the door is hot:

<u>Note:</u> If the door panel is hot, the fire is at a critical stage. Have extra fire fighting equipment available and ready to use.

PBE......DON

The door must be opened just enough to pass the nozzle of the extinguisher

(*)Repeat last three steps of the procedure, as necessary.

when safe:

FCRC DOOROPEN WITH CAUTION SOURCE OF SMOKE/FIRE.....LOCATE

Search all bunks, closets, and stowage compartments.

Continued on the following page



A350 MANUEL SECURITE SAUVETAGE

ABNORMAL/EMERGENCY PROCEDURES SMOKE AND FIRE PROCEDURES

###