

**L1 OPERATION**

1. Remove the infant life vest from its pouch and unroll it.
2. Place the infant life vest over the head of the infant and pull it down around the neck.
3. Place one infant's leg over the waistbelt harness loop and pull snug but not tight.
4. Run the waistbelt harness around back of the infant's waist and back to the front.
5. Close the buckle below the the life vest.
6. Adjust the waistbelt by pulling the loose end.
7. Pull the red inflator tags to inflate the infant life vest.
- 8.

**CAUTION**

Oral inflation prior to gas inflation will cause excessive pressure which may burst the life vest.

Use the oral inflation system if more or less pressure in the life vest is necessary:

- Blow into the tube to inflate
- Press the valve to deflate the life vest.